§ 150.380

§150.380 Under what circumstances may vessels operate within the safety zone or area to be avoided?

zone where a vessel may operate and the clearance needed for that location.

(a) Table 150.380(a) of this section lists both the areas within a safety

TABLE 150.380(a)—REGULATED ACTIVITIES OF VESSELS AT DEEPWATER PORTS

Regulated activities	Safety zone	Areas to be avoided around each deepwater port component 1	Anchorage areas	Other areas with- in and adjacent to the safety zone (e.g., no anchor- ing area)
Tankers calling at port	С	С	С	С
Support vessel movements	С	С	С	С
Transit by vessels other than tankers or support vessels.	F	D	P	P
Mooring to surface components (for example an SPM) by vessels other than tankers or support vessels.	N	N	N	N
Anchoring by vessels other than tankers or support vessels.	N	F	С	F
Fishing, including bottom trawl (shrimping)	N	D	P	N
Mobile drilling operations or erection of struc- tures. ²	N	R	N	N
Lightering/transshipment	N	N	N	N

Areas to be avoided are in subpart J of this part.

(b) If the activity is not listed in table 150.380(a) of this section, nor otherwise provided for in this subpart, the Captain of the Port's permission is required before operating in the safety zone or regulated navigation area.

$\S 150.385$ What is required in an emergency?

In an emergency, for the protection of life or property, a vessel may deviate from a vessel movement requirement in this subpart without clearance from a manned deepwater port's person in charge of vessel operations if the master advises the port person in charge of the reasons for the deviation at the earliest possible moment.

Subpart E—Cargo Transfer Operations

§ 150.400 What does this subpart do?

This subpart prescribes rules that apply to the transfer of oil or natural gas at a deepwater port.

§150.405 How must a cargo transfer system be tested and inspected?

- (a) No person may transfer oil or natural gas through a cargo transfer system (CTS) at a deepwater port unless it has been inspected and tested according to this section.
- (b) The single point mooring (SPM)-CTS must be maintained as required by the design standards used to comply with §149.650 of this chapter.
- (c) If the manufacturer's maximum pressure rating for any cargo transfer hose in a SPM-CTS has been exceeded, unless it was exceeded for testing required by this section, the hose must be:

Not part of Port Installation.

Not part of Port installation.

Key to regulated activities for Table 150.380(a):

C—Movement of the vessel is permitted when cleared by the person in charge of vessel operations.

D—Movement is not restricted, but recommended transit speed not to exceed 10 knots. Communication with the person in

D—Movement is not restricted, but recommended transit speed not to exceed to knots. Communication with the person in charge of vessel operations.

F—Only in an emergency. Anchoring will be avoided in a no anchoring area except in the case of immediate danger to the ship or persons on board.

N—Not permitted.

P—Transit is permitted when the vessel is not in the immediate area of a tanker, and when cleared by the vessel traffic super-

P—Transit is permitted when the Vocania and the Vocania and the Visor.

R—Permitted only if determined that operation does not create unacceptable risk to personnel safety and security and operation. For transiting foreign-flag vessels, the requirement for clearance to enter the area to be avoided and no anchoring area is advisory in nature, but mandatory for an anchorage area established within 12 nautical miles.